



BASIC BODY MAINTENANCE

- A. Wash the outside of the Hotshot Body at least once a month.
- B. Wash or steam clean interior once a month or as needed in case of food spills.
- C. Wax the outside at least 2 times a year.
- D. Lube hinges with white lithium grease once a month.
- E. Check tightness of screws on hinges & handles once a month.
- F. Check body mount bolts for tightness at least once a year.
- G. Check interior and exterior lights for proper operation.
- H. Check grille on condenser unit to be sure that it is clear of obstructions monthly.

For additional information and troubleshooting guide go to

www.hotshotdelivers.com

and click on the **SUPPORT** link.